CICADA & FAVERO_FS1

Connection Manual

1. Connecting the software.

Select connection type.

If you connect FAVERO FS1 with CICADA by Serial Port, Select Type with 'Serial Port', then Select an Available Serial Port;



If you connect FAVERO FS1 with CICADA by Network, you should select 'Type' with Network (TCP), then setup the Network IP and Network Port. The default IP is 192.168.0.100 and default port is 5000

2. The following variables was supported

Name	**Description**
Match:Time	Game clock
Match:ShotClock	Shot clock
Match:Period	
TeamA:Possession	Home team possession
TeamB:Possession	Guest team possession
TeamA:Score	Home team score
TeamB:Score	Guest team score
TeamA:Foul	Home team foul
TeamB:Foul	Guest team foul
Fouls:PlayerNumber	Player number who get foul
Fouls:Value	Fouls of the Player whose number is 'Fouls:PlayerNumber'